

TEK053

AUDI

A4 (8D, B5) 1.6 74KW(100PS/HP) - 1595cc - Μηχανή ADP, AHL, ANA, ARM	(11/94-09/01)	Boite 01V
A4 (8D, B5) 1.8 20V 85KW(115PS/HP) - 1781cc - Μηχανή AFY	(04/95-10/01)	Boite 01V
A4 (8D, B5) 1.8 20V 92KW(125PS/HP) - 1781cc - Μηχανή ADR, APT, ARG	(11/94-09/01)	Boite 01V
A4 (8D, B5) 1.8 20V Turbo 131KW(180PS/HP) - 1781cc - Μηχανή AJL	(12/97-09/01)	Boite 01V
A4 (8D, B5) 1.8 20V Turbo 110KW(150PS/HP) - 1781cc - Μηχανή AEB, ANB, APU, ARK, AWT	(11/94-09/01)	Boite 01V
A4 (8D, B5) 1.9 TD 55KW(75PS/HP) - 1896cc - Μηχανή AFF	(03/96-10/01)	Boite 01V
A4 (8D, B5) 1.9 TDi 66KW(90PS/HP) - 1896cc - Μηχανή 1Z, AHU, AHH	(11/94-09/01)	Boite 01V
A4 (8D, B5) 1.9 TDi 81KW(110PS/HP) - 1896cc - Μηχανή AFN, AVG	(11/94-09/01)	Boite 01V
A4 (8D, B5) 1.9 TDi 85KW(115PS/HP) - 1896cc - Μηχανή AJM, ATJ	(04/99-09/01)	Boite 01V
A4 (8D, B5) 2.4 V6 123KW(165PS/HP) - 2393cc - Μηχανή AGA, ALF, AJG, AML, APS, APZ, ARJ	(03/97-09/01)	Boite 01V
A4 (8D, B5) 2.5 TDi V6 110KW(150PS/HP) - 2496cc - Μηχανή AFB, AKN	(10/97-09/01)	Boite 01V
A4 (8D, B5) 2.6 110KW(150PS/HP) - 2598cc - Μηχανή ABC, ACZ	(11/94-09/01)	Boite 01V
A4 (8D, B5) 2.8 128KW(174PS/HP) - 2771cc - Μηχανή AAH, AFC	(11/94-07/97)	Boite 01V
A4 (8D, B5) 2.8 142KW(193PS/HP) - 2771cc - Μηχανή ACK, ALG, APR, AQD, ATX	(10/96-09/01)	Boite 01V
A4 (8D, B5) RS4 2.7 V6 Biturbo 280KW(380PS/HP) - 2671cc - Μηχανή ASJ, AZR	(05/00-09/01)	Boite 01V
A4 (8D, B5) S4 2.7 V6 30V 195KW(265PS/HP) - 2671cc - Μηχανή AGB	(09/97-11/00)	Boite 01V
A4 (8E, 8H, B6) 1.6 75KW(102PS/HP) - 1595cc - Μηχανή ALZ	(01/01-06/08)	Boite 01V
A4 (8E, 8H, B6) 1.8 20V Turbo 120KW(163PS/HP) - 1781cc - Μηχανή BFB	(11/04-09/08)	Boite 01V
A4 (8E, 8H, B6) 1.8 20V Turbo 120KW(163PS/HP) - 1781cc - Μηχανή BFB	(06/02-09/08)	Boite 01V
A4 (8E, 8H, B6) 1.8 20V Turbo 125KW(170PS/HP) - 1781cc - Μηχανή AMB	(07/01-12/04)	Boite 01V
A4 (8E, 8H, B6) 1.8 20V Turbo 110KW(150PS/HP) - 1781cc - Μηχανή AVJ, AUM	(11/00-08/02)	Boite 01V
A4 (8E, 8H, B6) 1.8 20V Turbo 140KW(190PS/HP) - 1781cc - Μηχανή BEX	(11/02-12/04)	Boite 01V
A4 (8E, 8H, B6) 1.9 TDi 85KW(115PS/HP) - 1896cc - Μηχανή BKE, BRB	(05/04-06/08)	Boite 01V
A4 (8E, 8H, B6) 1.9 TDi 73KW(100PS/HP) - 1896cc - Μηχανή AVB	(03/01-08/04)	Boite 01V
A4 (8E, 8H, B6) 1.9 TDi 96KW(130PS/HP) - 1896cc - Μηχανή AVF, AWW	(11/00-06/08)	Boite 01V
A4 (8E, 8H, B6) 2.0 20V 96KW(130PS/HP) - 1984cc - Μηχανή ALT	(11/00-06/08)	Boite 01V

A4 (8E, 8H, B6) 2.0 FSi 110KW(150PS/HP) - 1984cc - Μηχανή AWA	(07/02-01/05)	Boite 01V
A4 (8E, 8H, B6) 2.0 TDi 125KW(170PS/HP) - 1968cc - Μηχανή BRD, BVA	(05/06-06/08)	Boite 01V
A4 (8E, 8H, B6) 2.0 TDi 103KW(140PS/HP) - 1968cc - Μηχανή BLB, BNA, BRE, BRF	(11/04-06/08)	Boite 01V
A4 (8E, 8H, B6) 2.0 TFSi 147KW(200PS/HP) - 1984cc - Μηχανή BGB, BWE	(11/04-09/08)	Boite 01V
A4 (8E, 8H, B6) 2.0 TFSi 162KW(220PS/HP) - 1984cc - Μηχανή BUL	(06/05-06/08)	Boite 01V
A4 (8E, 8H, B6) 2.4 V6 125KW(170PS/HP) - 2393cc - Μηχανή BDV	(09/01-06/08)	Boite 01V
A4 (8E, 8H, B6) 2.4 V6 120KW(163PS/HP) - 2393cc - Μηχανή AMM	(09/01-06/08)	Boite 01V
A4 (8E, 8H, B6) 2.5 TDi V6 131KW(180PS/HP) - 2496cc - Μηχανή AKE, BAU, BDH	(11/00-12/05)	Boite 01V
A4 (8E, 8H, B6) 2.5 TDi V6 120KW(163PS/HP) - 2496cc - Μηχανή BCZ	(11/04-12/05)	Boite 01V
A4 (8E, 8H, B6) 2.5 TDi V6 115KW(155PS/HP) - 2496cc - Μηχανή AYM	(04/01-08/02)	Boite 01V
A4 (8E, 8H, B6) 2.7 TDi V6 132KW(180PS/HP) - 2698cc - Μηχανή BPP	(11/05-09/08)	Boite 01V
A4 (8E, 8H, B6) 3.0 TDi V6 171KW(233PS/HP) - 2967cc - Μηχανή ASB	(11/05-09/08)	Boite 01V
A4 (8E, 8H, B6) 3.0 TDi V6 150KW(204PS/HP) - 2967cc - Μηχανή BKN	(11/04-06/08)	Boite 01V
A4 (8E, 8H, B6) 3.0 V6 30V 162KW(220PS/HP) - 2976cc - Μηχανή ASN, AVK, BBJ	(11/00-06/08)	Boite 01V
A4 (8E, 8H, B6) 3.2 FSi 188KW(256PS/HP) - 3123cc - Μηχανή AUK	(11/04-06/08)	Boite 01V
A4 (8E, 8H, B6) RS4 4.2 V8 309KW(420PS/HP) - 4163cc - Μηχανή BNS	(09/05-12/08)	Boite 01V
A4 (8E, 8H, B6) S4 4.2 V8 24V 253KW(344PS/HP) - 4163cc - Μηχανή BBK, BHF	(02/03-12/08)	Boite 01V
A6 (4A, 4B, C4, C5) 1.8 85KW(116PS/HP) - 1781cc - Μηχανή AFY	(05/97-07/05)	Boite 01V
A6 (4A, 4B, C4, C5) 1.8 92KW(125PS/HP) - 1781cc - Μηχανή AJP, AQE, ARH	(07/97-06/01)	Boite 01V
A6 (4A, 4B, C4, C5) 1.8 20V 92KW(125PS/HP) - 1781cc - Μηχανή ADR	(12/95-02/97)	Boite 01V
A6 (4A, 4B, C4, C5) 1.8 20V Turbo 110KW(150PS/HP) - 1781cc - Μηχανή AEB, ANB, APU, ARK, AWL, AWT	(01/97-07/05)	Boite 01V
A6 (4A, 4B, C4, C5) 1.8 20V Turbo 132KW(180PS/HP) - 1781cc - Μηχανή AJL	(12/97-07/05)	Boite 01V
A6 (4A, 4B, C4, C5) 1.9 TDi 85KW(115PS/HP) - 1896cc - Μηχανή AJM	(11/00-06/01)	Boite 01V
A6 (4A, 4B, C4, C5) 1.9 TDi 81KW(110PS/HP) - 1896cc - Μηχανή AFN, AVG	(02/97-12/00)	Boite 01V
A6 (4A, 4B, C4, C5) 1.9 TDi 96KW(130PS/HP) - 1896cc - Μηχανή AWX	(05/01-07/05)	Boite 01V
A6 (4A, 4B, C4, C5) 1.9 TDi 66KW(90PS/HP) - 1896cc - Μηχανή IZ	(06/94-02/97)	Boite 01V
A6 (4A, 4B, C4, C5) 2.0 85KW(116PS/HP) - 1984cc - Μηχανή ABK	(06/94-02/97)	Boite 01V
A6 (4A, 4B, C4, C5) 2.0 74KW(101PS/HP) - 1984cc - Μηχανή AAE	(06/94-02/97)	Boite 01V
A6 (4A, 4B, C4, C5) 2.0 20V 96KW(130PS/HP) - 1984cc - Μηχανή ALT	(05/01-07/05)	Boite 01V
A6 (4A, 4B, C4, C5) 2.3 98KW(133PS/HP) - 2309cc - Μηχανή AAR	(06/94-12/95)	Boite 01V
A6 (4A, 4B, C4, C5) 2.4	(07/95-10/97)	Boite 01V

110KW(150PS/HP) - 2393cc - Μηχανή AFM	Boite 01V
A6 (4A, 4B, C4, C5) 2.4	(06/01-07/05)
125KW(170PS/HP) - 2393cc - Μηχανή BDV	Boite 01V
A6 (4A, 4B, C4, C5) 2.4	(02/97-06/01)
121KW(165PS/HP) - 2393cc - Μηχανή AGA, AJG, ALF, ALW, APS, APZ, ARJ, ARN	Boite 01V
A6 (4A, 4B, C4, C5) 2.4	(07/98-06/01)
100KW(136PS/HP) - 2393cc - Μηχανή ALW	Boite 01V
A6 (4A, 4B, C4, C5) 2.4	(02/97-07/05)
115KW(156PS/HP) - 2393cc - Μηχανή APC	Boite 01V
A6 (4A, 4B, C4, C5) 2.5 Tdi	(07/97-06/01)
110KW(150PS/HP) - 2496cc - Μηχανή AFB, AKN	Boite 01V
A6 (4A, 4B, C4, C5) 2.5 TDi	(06/94-02/97)
85KW(116PS/HP) - 2496cc - Μηχανή AAT	Boite 01V
A6 (4A, 4B, C4, C5) 2.5 Tdi	(07/99-07/05)
132KW(180PS/HP) - 2496cc - Μηχανή AKE, BAU, BDH	Boite 01V
A6 (4A, 4B, C4, C5) 2.5 Tdi	(07/02-07/05)
120KW(163PS/HP) - 2496cc - Μηχανή BCZ, BDG, BFC	Boite 01V
A6 (4A, 4B, C4, C5) 2.5 Tdi	(04/01-07/05)
115KW(155PS/HP) - 2496cc - Μηχανή AYM	Boite 01V
A6 (4A, 4B, C4, C5) 2.6 V6	(06/94-02/97)
102KW(139PS/HP) - 2598cc - Μηχανή ACZ	Boite 01V
A6 (4A, 4B, C4, C5) 2.6 V6	(06/94-02/97)
110KW(150PS/HP) - 2598cc - Μηχανή ABC	Boite 01V
A6 (4A, 4B, C4, C5) 2.7 T V6	(12/97-06/01)
169KW(230PS/HP) - 2671cc - Μηχανή AJK	Boite 01V
A6 (4A, 4B, C4, C5) 2.7 T V6	(01/99-06/01)
169KW(230PS/HP) - 2671cc - Μηχανή AJK, AZA	Boite 01V
A6 (4A, 4B, C4, C5) 2.7 T V6	(05/00-07/05)
184KW(250PS/HP) - 2671cc - Μηχανή ARE	Boite 01V
A6 (4A, 4B, C4, C5) 2.8 V6	(06/94-02/97)
128KW(174PS/HP) - 2771cc - Μηχανή AAH	Boite 01V
A6 (4A, 4B, C4, C5) 2.8 V6	(07/99-06/01)
140KW(190PS/HP) - 2771cc - Μηχανή ATX	Boite 01V
A6 (4A, 4B, C4, C5) 2.8 V6	(02/97-06/01)
142KW(193PS/HP) - 2771cc - Μηχανή ACK, ALG, APR, AQD	Boite 01V
A6 (4A, 4B, C4, C5) 2.8 V6	(06/94-07/95)
120KW(163PS/HP) - 2771cc - Μηχανή AEJ	Boite 01V
A6 (4A, 4B, C4, C5) 2.8 V6	(10/97-07/98)
132KW(180PS/HP) - 2771cc - Μηχανή AGE	Boite 01V
A6 (4A, 4B, C4, C5) 2.8 V6	(12/95-02/97)
142KW(193PS/HP) - 2771cc - Μηχανή ACK, ALG, APR, AQD	Boite 01V
A6 (4A, 4B, C4, C5) 3.0 V6	(05/01-07/05)
162KW(220PS/HP) - 2976cc - Μηχανή ASN	Boite 01V
A6 (4A, 4B, C4, C5) 3.7 V8	(06/99-07/05)
191KW(260PS/HP) - 3697cc - Μηχανή AQG	Boite 01V
A6 (4A, 4B, C4, C5) 4.2	(11/98-07/05)
220KW(300PS/HP) - 4172cc - Μηχανή ARS, ART, ASG, AWN	Boite 01V
A6 (4A, 4B, C4, C5) RS6 4.2 V8 Biturbo	(07/02-10/04)
330KW(450PS/HP) - 4172cc - Μηχανή BCY	
A6 (4A, 4B, C4, C5) RS6 Plus 4.2 V8 Biturbo	(04/04-10/04)
353KW(480PS/HP) - 4172cc - Μηχανή BRV	
A6 (4A, 4B, C4, C5) S6 4.2 V8	(07/99-07/05)
250KW(340PS/HP) - 4172cc - Μηχανή AQJ, ANK	
A8 (4D) 2.5 TDi V6	(04/00-10/02)
131KW(180PS/HP) - 2496cc - Μηχανή AKE	Boite 01V
A8 (4D) 2.5 TDi V6	(07/97-10/02)
110KW(150PS/HP) - 2496cc - Μηχανή AFB, AKN	Boite 01V
A8 (4D) 2.8 V6 30V	(04/96-10/02)
142KW(193PS/HP) - 2771cc - Μηχανή ACK, ALG, AMX, APR, AQD	Boite 01V
A8 (4D) 2.8E	(03/94-03/96)
128KW(174PS/HP) - 2771cc - Μηχανή AAH	Boite 01V

A8 (4D) 3.3 TDi V8 167KW(225PS/HP) - 3328cc - Μηχανή AKF	(09/99-10/02)	Boite 01V
A8 (4D) 3.7 169KW(230PS/HP) - 3697cc - Μηχανή AEW, AKJ	(07/95-10/02)	Boite 01V
A8 (4D) 3.7 V8 40V 191KW(260PS/HP) - 3697cc - Μηχανή AQG, AKC	(10/98-10/02)	Boite 01V
A8 (4D) 4.2 V8 220KW(300PS/HP) - 4172cc - Μηχανή ABZ	(03/94-07/96)	Boite 01V
A8 (4D) 4.2 V8 175KW(239PS/HP) - 4172cc - Μηχανή ARU, AVN	(05/99-10/02)	Boite 01V
A8 (4D) 4.2 V8 264KW(360PS/HP) - 4172cc - Μηχανή AQH, AVP	(05/99-10/02)	Boite 01V
A8 (4D) 4.2 V8 40V 228KW(310PS/HP) - 4172cc - Μηχανή AQF, AUX, AUW	(10/98-10/02)	Boite 01V
A8 (4D) 6.0 W12 309KW(420PS/HP) - 5998cc - Μηχανή AZC	(06/01-10/02)	Boite 01V
A8 (4D) S8 4.2 250KW(340PS/HP) - 4172cc - Μηχανή AHC	(07/96-10/02)	
Allroad (4BH) 2.5 TDi V6 132KW(180PS/HP) - 2496cc - Μηχανή AKE, BAU	(05/00-08/05)	
Allroad (4BH) 2.7 Turbo V6 184KW(250PS/HP) - 2671cc - Μηχανή ARE, BES	(05/00-08/05)	
Allroad (4BH) 4.2 V8 220KW(300PS/HP) - 4163cc - Μηχανή BAS	(06/02-08/05)	

PORSCHE

Boxster (987) 2.7 176KW(240PS/HP) - 2687cc - Μηχανή M 96.25	(11/04-12/08)	
Boxster (987) 2.7 180KW(245PS/HP) - 2687cc - Μηχανή M97.20	(08/06-01/09)	
Boxster (987) S 3,4 223KW(303PS/HP) - 3387cc - Μηχανή M9722	(01/08-12/10)	
Boxster (987) S 3.2 206KW(280PS/HP) - 3179cc - Μηχανή M 96.26	(11/04-01/09)	
Boxster (987) S 3.4 217KW(295PS/HP) - 3387cc - Μηχανή M97.21	(08/06-12/10)	
Boxster 2.5i (986) 150KW(204PS/HP) - 2480cc - Μηχανή M96.20	(09/96-05/00)	
Boxster 2.7 (986) 155KW(208PS/HP) - 2687cc - Μηχανή M9622	(06/99-12/01)	
Boxster 2.7 (986) 168KW(228PS/HP) - 2687cc - Μηχανή M9623	(08/02-07/04)	
Boxster 2.7i (986) 162KW(220PS/HP) - 2687cc - Μηχανή M96.22, M96.23	(08/99-02/05)	
Boxster S 3.2 24V 196KW(266PS/HP) - 3179cc - Μηχανή M96.24S	(01/04-12/04)	
Boxster S 3.2 24V 185/191KW(252/260PS/HP) - 3179cc - Μηχανή M96.21, M96.24	(08/99-02/05)	
Cayman (987) 2.7 180KW(245PS/HP) - 2687cc - Μηχανή M 97.20	(07/06-01/09)	
Cayman (987) S 3.4 217KW(295PS/HP) - 3387cc - Μηχανή M 97.21	(11/05-01/09)	
Cayman (987) S 3.4 223KW(299PS/HP) - 3387cc - Μηχανή M9722	(08/08-01/09)	

SKODA

Superb I 1.8 20V Turbo 110KW(150PS/HP) - 1781cc - Μηχανή AWT	(06/02-03/08)	
Superb I 1.9 TDi 96KW(130PS/HP) - 1896cc - Μηχανή AWX	(06/02-03/08)	

Superb I 1.9 TDi 77KW(105PS/HP) - 1896cc - Μηχανή BSV	(09/05-05/07)
Superb I 1.9 TDi 85KW(115PS/HP) - 1896cc - Μηχανή BPZ	(02/07-03/08)
Superb I 1.9 TDi 74KW(100PS/HP) - 1896cc - Μηχανή AVB	(06/02-10/05)
Superb I 2.0 85KW(115PS/HP) - 1984cc - Μηχανή AZM	(06/02-03/08)
Superb I 2.0 TDi 103KW(140PS/HP) - 1968cc - Μηχανή BSS	(09/05-03/08)
Superb I 2.5 TDi V6 114KW(155PS/HP) - 2496cc - Μηχανή AYM	(06/02-08/03)
Superb I 2.5 TDi V6 120KW(163PS/HP) - 2496cc - Μηχανή BDG	(06/03-03/08)
Superb I 2.8 V6 142KW(193PS/HP) - 2771cc - Μηχανή AMX, BBG	(06/02-03/08)

VOLKSWAGEN

Passat (3B2/3B5) 1.6 74KW(101PS/HP) - 1595cc - Μηχανή ADP, AHL, ANA, ARM	(10/96-12/00)	Boite 01V
Passat (3B2/3B5) 1.8 85KW(116PS/HP) - 1781cc - Μηχανή AFY	(01/97-11/00)	Boite 01V
Passat (3B2/3B5) 1.8 20V 92KW(125PS/HP) - 1781cc - Μηχανή ADR, APW, ARG	(10/96-12/00)	Boite 01V
Passat (3B2/3B5) 1.8 20V Turbo 110KW(150PS/HP) - 1781cc - Μηχανή AEB, ANB, APU	(10/96-12/00)	
Passat (3B2/3B5) 1.9 TDi 85KW(115PS/HP) - 1896cc - Μηχανή AJM, ATJ	(08/98-12/00)	Boite 01V
Passat (3B2/3B5) 1.9 TDi 66KW(90PS/HP) - 1896cc - Μηχανή AHH, AHU	(10/96-12/00)	Boite 01V
Passat (3B2/3B5) 1.9 TDi 81KW(110PS/HP) - 1896cc - Μηχανή AFN, AVG	(10/96-12/00)	Boite 01V
Passat (3B2/3B5) 2.3 V5 110KW(150PS/HP) - 2324cc - Μηχανή AGZ	(10/96-10/00)	Boite 01V
Passat (3B2/3B5) 2.5 TDi V6 110KW(150PS/HP) - 2496cc - Μηχανή AFB	(11/98-12/00)	Boite 01V
Passat (3B2/3B5) 2.8 V6 142KW(193PS/HP) - 2771cc - Μηχανή ACK, ALG	(10/96-12/00)	Boite 01V
Passat (3B2/3B5) 2.8 V6 132KW(180PS/HP) - 2771cc - Μηχανή AGE	(05/97-09/99)	Boite 01V
Passat (3B3/3B6) 1.6 75KW(102PS/HP) - 1595cc - Μηχανή ALZ	(11/00-09/05)	Boite 01V
Passat (3B3/3B6) 1.8 20V Turbo 110KW(150PS/HP) - 1781cc - Μηχανή AWT	(11/00-09/05)	Boite 01V
Passat (3B3/3B6) 1.9 TDi 74KW(101PS/HP) - 1896cc - Μηχανή AVB	(11/00-09/05)	Boite 01V
Passat (3B3/3B6) 1.9 TDi 96KW(130PS/HP) - 1896cc - Μηχανή AVF, AWX	(11/00-09/05)	Boite 01V
Passat (3B3/3B6) 2.0 85KW(115PS/HP) - 1984cc - Μηχανή AZM	(11/00-09/05)	Boite 01V
Passat (3B3/3B6) 2.0 96KW(130PS/HP) - 1984cc - Μηχανή ALT	(11/01-09/05)	Boite 01V
Passat (3B3/3B6) 2.0 TDi 100KW(136PS/HP) - 1968cc - Μηχανή BGW, BHW	(12/03-09/05)	Boite 01V
Passat (3B3/3B6) 2.3 V5 20V 125KW(170PS/HP) - 2324cc - Μηχανή AZX	(11/00-09/05)	Boite 01V
Passat (3B3/3B6) 2.5 TDi V6 132KW(180PS/HP) - 2496cc - Μηχανή BDH	(01/03-09/05)	Boite 01V
Passat (3B3/3B6) 2.5 TDi V6 110KW(150PS/HP) - 2496cc - Μηχανή AKN	(11/00-09/05)	Boite 01V

03/11/2023

Passat (3B3/3B6) 2.5 TDi V6 120KW(163PS/HP) - 2496cc - Μηχανή BAU	(05/03-09/05)	Boite 01V
Passat (3B3/3B6) 2.8 VR6 142KW(193PS/HP) - 2771cc - Μηχανή AMX, ATQ, BBG	(11/00-09/05)	Boite 01V
Passat (3B3/3B6) 4.0 W8 4-Motion 202KW(275PS/HP) - 3999cc - Μηχανή BDN	(11/01-12/04)	Boite 01V
Passat (3B3/3B6) 1.8 20V Turbo 125KW(170PS/HP) - 1781cc - Μηχανή AWM	(02/01-09/05)	Boite 01V
Passat (3C2/3C5) 1.6 FSi 85KW(115PS/HP) - 1598cc - Μηχανή BLF	(03/05-06/08)	Boite 01V
Passat (3C2/3C5) 2.0 FSi 110KW(150PS/HP) - 1984cc - Μηχανή BLR, BLX, BLY, BVX, BVY, BVZ	(03/05-11/10)	Boite 01V
Passat (3C2/3C5) 2.0 TDi 103KW(140PS/HP) - 1968cc - Μηχανή BKP, BMP, CBAB	(03/05-07/10)	Boite 01V
Passat (3C2/3C5) 3.2 FSi 184KW(250PS/HP) - 3168cc - Μηχανή AXZ	(11/05-11/10)	Boite 01V
Phaeton 3.0 TDi V6 165KW(224PS/HP) - 2967cc - Μηχανή BMK	(09/04-07/07)	Boite 01V
Phaeton 3.2 V6 177KW(241PS/HP) - 3189cc - Μηχανή AYT, BKL, BRK	(03/02-05/07)	Boite 01V
Phaeton 4.2 V8 246KW(335PS/HP) - 4172cc - Μηχανή BGH, BGJ	(07/03-)	Boite 01V
Phaeton 5.0 TDi V10 230KW(313PS/HP) - 4921cc - Μηχανή AJS	(03/03-05/06)	Boite 01V
Phaeton 6.0 W12 331KW(450PS/HP) - 5998cc - Μηχανή BRN, BTT	(06/05-)	Boite 01V
Phaeton 6.0 W12 309KW(420PS/HP) - 5998cc - Μηχανή BAN	(03/02-05/05)	Boite 01V
Transporter T4 2.4 Diesel 57KW(78PS/HP) - 2370cc - Μηχανή AAB	(10/90-08/03)	