

TEK052

FORD

C-Max I 1.6 16V 85KW(116PS/HP) - 1596cc - Motor HXDA/HXDB/SIDA	(04/07-09/10)	Boite 4F27E avtomatski menjalnik s 4.prestavami
C-Max I 1.6 16V 74KW(100PS/HP) - 1596cc - Motor Duratec	(05/07-08/10)	Boite 4F27E avtomatski menjalnik s 4.prestavami
C-Max I 1.6 TDCi 74KW(101PS/HP) - 1560cc - Motor Duratorq	(02/07-09/10)	Boite 4F27E avtomatski menjalnik s 4.prestavami
C-Max I 1.6 TDCi 80KW(110PS/HP) - 1560cc - Motor Duratorq	(05/07-08/10)	Boite 4F27E avtomatski menjalnik s 4.prestavami
C-Max I 1.6 TDCi 66KW(90PS/HP) - 1560cc - Motor Duratorq	(05/07-08/10)	Boite 4F27E avtomatski menjalnik s 4.prestavami
C-Max I 1.8 16V, Flexifuel 92KW(125PS/HP) - 1798cc - Motor Duratec	(05/07-08/10)	Boite 4F27E avtomatski menjalnik s 4.prestavami
C-Max I 1.8 TDCi 85KW(115PS/HP) - 1753cc - Motor KKDA	(05/07-08/10)	Boite 4F27E avtomatski menjalnik s 4.prestavami
C-Max I 2.0 16V 107KW(145PS/HP) - 1999cc - Motor Duratec	(05/07-08/10)	Boite 4F27E avtomatski menjalnik s 4.prestavami
C-Max I 2.0 CNG 107KW(145PS/HP) - 1999cc - Motor Duratec	(04/09-08/10)	Boite 4F27E avtomatski menjalnik s 4.prestavami
C-Max I 2.0 TDCi 81KW(110PS/HP) - 1997cc - Motor Duratorq	(05/07-09/10)	Boite 4F27E avtomatski menjalnik s 4.prestavami
C-Max I 2.0 TDCi 100KW(136PS/HP) - 1997cc - Motor G6DA, G6DB, G6DD, G6DG	(05/07-09/10)	Boite 4F27E avtomatski menjalnik s 4.prestavami
Fiesta VI 1.25 60KW(82PS/HP) - 1242cc - Motor SNJA, SNJB, SNJC, SNJD	(10/08-)	Boite 4F27E avtomatski menjalnik s 4.prestavami
Fiesta VI 1.25 44KW(60PS/HP) - 1242cc - Motor STJA, STJB, STJC, STJD	(10/08-)	Boite 4F27E avtomatski menjalnik s 4.prestavami
Fiesta VI 1.4 16V 71KW(96PS/HP) - 1388cc - Motor SPJA, SPJC, SPJE	(10/08-)	Boite 4F27E avtomatski menjalnik s 4.prestavami
Fiesta VI 1.4 16V (LPG prepared) 68KW(91PS/HP) - 1388cc - Motor RTJA, RTJB	(01/09-)	Boite 4F27E avtomatski menjalnik s 4.prestavami
Fiesta VI 1.4 TDCi 50KW(68PS/HP) - 1398cc - Motor F6JB	(10/08-06/10)	Boite 4F27E avtomatski menjalnik s 4.prestavami
Fiesta VI 1.4 TDCi 51KW(70PS/HP) - 1399cc - Motor KVJA	(07/10-)	Boite 4F27E avtomatski menjalnik s 4.prestavami
Fiesta VI 1.6 16V 99KW(134PS/HP) - 1596cc - Motor C16HDEZ	(12/10-)	Boite 4F27E avtomatski menjalnik s 4.prestavami
Fiesta VI 1.6 16V 88KW(120PS/HP) - 1596cc - Motor HXJA	(10/08-)	Boite 4F27E avtomatski menjalnik s 4.prestavami
Fiesta VI 1.6 TDCi 70KW(95PS/HP) - 1560cc - Motor C16DSOX	(04/10-)	Boite 4F27E avtomatski menjalnik s 4.prestavami
Fiesta VI 1.6 TDCi 66KW(90PS/HP) - 1560cc - Motor HHJD	(10/08-03/10)	Boite 4F27E avtomatski menjalnik s 4.prestavami
Focus C-Max 1.6 16V 74KW(100PS/HP) - 1596cc - Motor Duratec	(10/03-05/07)	Boite 4F27E avtomatski menjalnik s 4.prestavami
Focus C-Max 1.6 16V Ti-VCT 85KW(115PS/HP) - 1596cc - Motor Duratec	(08/04-05/07)	Boite 4F27E avtomatski menjalnik s 4.prestavami
Focus C-Max 1.6 TDCi 66KW(90PS/HP) - 1560cc - Motor HHDA, HHDB	(02/05-05/07)	Boite 4F27E avtomatski menjalnik s 4.prestavami
Focus C-Max 1.6 TDCi 80KW(109PS/HP) - 1560cc - Motor G8DA, G8DB	(09/03-05/07)	Boite 4F27E avtomatski menjalnik s 4.prestavami
Focus C-Max 1.8 16V 88KW(120PS/HP) - 1798cc - Motor Duratec, CSDA	(09/03-05/07)	Boite 4F27E avtomatski menjalnik s 4.prestavami

Focus C-Max 1.8 16V 92KW(125PS/HP) - 1798cc - Motor Duratec	(04/04-05/07)	Boite 4F27E avtomatski menjalnik s 4.prestavami
Focus C-Max 1.8 16V FFV 92KW(125PS/HP) - 1798cc - Motor Duratec	(01/06-05/07)	Boite 4F27E avtomatski menjalnik s 4.prestavami
Focus C-Max 1.8 TDCi 85KW(115PS/HP) - 1753cc - Motor KKDA	(04/05-05/07)	Boite 4F27E avtomatski menjalnik s 4.prestavami
Focus C-Max 2.0 16V 107KW(145PS/HP) - 1999cc - Motor Duratec, A0DA, A0DB, A0DE, SYDA	(04/04-05/07)	Boite 4F27E avtomatski menjalnik s 4.prestavami
Focus C-Max 2.0 TDCi 98KW(133PS/HP) - 1997cc - Motor G6DC, G6DE, G6DF	(10/03-03/07)	Boite 4F27E avtomatski menjalnik s 4.prestavami
Focus C-Max 2.0 TDCi 100KW(136PS/HP) - 1997cc - Motor DW10BTED4 (PSA)	(09/03-05/07)	Boite 4F27E avtomatski menjalnik s 4.prestavami
Focus I 1.4i 16V 55KW(75PS/HP) - 1391cc - Motor ZETEC-FXD	(09/98-12/04)	Boite 4F27E avtomatski menjalnik s 4.prestavami
Focus I 1.6i 16V 74KW(100PS/HP) - 1596cc - Motor ZETEC-FYD	(09/98-12/04)	Boite 4F27E avtomatski menjalnik s 4.prestavami
Focus I 1.8 TDCi 74KW(100PS/HP) - 1753cc - Motor FFDA	(09/02-12/04)	Boite 4F27E avtomatski menjalnik s 4.prestavami
Focus I 1.8 TDCi 85KW(115PS/HP) - 1753cc - Motor F9DA, F9DB	(04/01-12/04)	Boite 4F27E avtomatski menjalnik s 4.prestavami
Focus I 1.8 TDdi 55KW(75PS/HP) - 1753cc - Motor BHDA- BHDB	(03/00-03/05)	Boite 4F27E avtomatski menjalnik s 4.prestavami
Focus I 1.8 TDdi 66KW(90PS/HP) - 1753cc - Motor C9DA-C9DC-C9DB	(09/98-12/04)	Boite 4F27E avtomatski menjalnik s 4.prestavami
Focus I 1.8i 16V 85KW(115PS/HP) - 1796cc - Motor ZETEC-EYD	(09/98-12/04)	Boite 4F27E avtomatski menjalnik s 4.prestavami
Focus I 2.0i 16V 96KW(130PS/HP) - 1989cc - Motor ZETEC EDD	(09/98-12/04)	Boite 4F27E avtomatski menjalnik s 4.prestavami
Focus I 2.0i RS 158KW(215PS/HP) - 1989cc - Motor Duratec RS	(08/02-12/03)	Boite 4F27E avtomatski menjalnik s 4.prestavami
Focus I 2.0i ST 170 125KW(170PS/HP) - 1988cc - Motor Duratec ST	(03/02-12/04)	Boite 4F27E avtomatski menjalnik s 4.prestavami
Focus II 1.4 16V 59KW(80PS/HP) - 1388cc - Motor ASDA, ASDB	(11/04-09/12)	Boite 4F27E avtomatski menjalnik s 4.prestavami
Focus II 1.6 16V 74KW(100PS/HP) - 1596cc - Motor HWDA, HWDB, SHDA, SHDB, SHDC	(11/04-09/12)	Boite 4F27E avtomatski menjalnik s 4.prestavami
Focus II 1.6 16V Ti-VCT 85KW(115PS/HP) - 1596cc - Motor HXDA	(11/04-09/12)	Boite 4F27E avtomatski menjalnik s 4.prestavami
Focus II 1.6 TDCi 74/80KW(100/109PS/HP) - 1560cc - Motor G8DA, G8DB, G8DD, G8DE, G8DF, G8DA	(11/04-09/12)	Boite 4F27E avtomatski menjalnik s 4.prestavami
Focus II 1.6 TDCi 66KW(90PS/HP) - 1560cc - Motor GPDA, GPDB, GPDC, HHDA, HHDB	(01/05-09/12)	Boite 4F27E avtomatski menjalnik s 4.prestavami
Focus II 1.8 16V FFV 92KW(125PS/HP) - 1798cc - Motor Q7DA	(01/06-09/12)	Boite 4F27E avtomatski menjalnik s 4.prestavami
Focus II 1.8 TDCi 85KW(115PS/HP) - 1753cc - Motor KKDA	(04/05-09/12)	Boite 4F27E avtomatski menjalnik s 4.prestavami
Focus II 2.0 16V 106KW(145PS/HP) - 1999cc - Motor AODA, AODB	(11/04-09/12)	Boite 4F27E avtomatski menjalnik s 4.prestavami
Focus II 2.0 TDCi 81KW(109PS/HP) - 1997cc - Motor IXDA	(02/08-07/11)	Boite 4F27E avtomatski menjalnik s 4.prestavami
Focus II 2.0 TDCi 100KW(136PS/HP) - 1997cc - Motor G6DA, G6DB	(11/04-01/08)	Boite 4F27E avtomatski menjalnik s 4.prestavami
Focus II 2.5 RS 224KW(305PS/HP) - 2521cc - Motor JZDA	(03/09-07/11)	Boite 4F27E avtomatski menjalnik s 4.prestavami
Focus II 2.5 RS 500 257KW(350PS/HP) - 2521cc - Motor JZDA	(05/10-07/11)	Boite 4F27E avtomatski menjalnik s 4.prestavami
Focus II 2.5 ST 166KW(225PS/HP) - 2522cc - Motor HYDA	(10/05-09/12)	Boite 4F27E avtomatski menjalnik s 4.prestavami

MAZDA

3 (BK) 1.4 16V 62KW(84PS/HP) - 1349cc - Motor ZJ07, ZJ30	(10/03-06/09)	Boite 4F27E avtomatski menjalnik s 4.prestavami
3 (BK) 1.6 16V 77KW(105PS/HP) - 1598cc - Motor Z6	(10/03-06/09)	Boite 4F27E avtomatski menjalnik s 4.prestavami
3 (BK) 1.6 MZ-CD 80KW(109PS/HP) - 1560cc - Motor Y601	(03/04-06/09)	Boite 4F27E avtomatski menjalnik s 4.prestavami
3 (BK) 1.6 MZ-CD 66KW(90PS/HP) - 1560cc - Motor Y406	(09/12-)	Boite 4F27E avtomatski menjalnik s 4.prestavami
3 (BK) 2.0 16V 110KW(150PS/HP) - 1999cc - Motor LF17	(10/03-06/09)	Boite 4F27E avtomatski menjalnik s 4.prestavami
3 (BK) 2.0 MZ-CD 105KW(143PS/HP) - 1998cc - Motor RF7J, RF8G	(04/07-)	Boite 4F27E avtomatski menjalnik s 4.prestavami
3 (BK) 2.3 Turbo MPS 191KW(260PS/HP) - 2261cc - Motor MZR DISI	(12/06-06/09)	Boite 4F27E avtomatski menjalnik s 4.prestavami
323 1.5i 16V 65KW(88PS/HP) - 1498cc - Motor Z5	(09/98-02/01)	Boite 4F27E avtomatski menjalnik s 4.prestavami
323 1.6i 16V 72KW(98PS/HP) - 1598cc - Motor ZM	(03/01-05/04)	Boite 4F27E avtomatski menjalnik s 4.prestavami
323 1.8i 16V 84KW(114PS/HP) - 1840cc - Motor BP	(09/98-02/01)	Boite 4F27E avtomatski menjalnik s 4.prestavami
323 2.0i 16V 96KW(130PS/HP) - 1999cc - Motor FS	(02/00-05/04)	Boite 4F27E avtomatski menjalnik s 4.prestavami
5 (CR) 2.0 16V 107KW(146PS/HP) - 1999cc - Motor LFF7	(03/05-05/10)	Boite 4F27E avtomatski menjalnik s 4.prestavami
6 (GG, GY) 1.8 16V 88KW(120PS/HP) - 1798cc - Motor L813, L829	(05/02-01/08)	Boite 4F27E avtomatski menjalnik s 4.prestavami
6 (GG, GY) 2.0 16V 108KW(147PS/HP) - 1998cc - Motor LFF7	(03/05-01/08)	Boite 4F27E avtomatski menjalnik s 4.prestavami
6 (GG, GY) 2.0 16V 104KW(141PS/HP) - 1999cc - Motor LV	(05/02-01/08)	Boite 4F27E avtomatski menjalnik s 4.prestavami
6 (GG, GY) 2.0 Di MZR-CD 89KW(120PS/HP) - 1998cc - Motor RF5C	(08/02-02/05)	Boite 4F27E avtomatski menjalnik s 4.prestavami
6 (GG, GY) 2.0 Di MZR-CD 105KW(143PS/HP) - 1998cc - Motor RF7J	(09/05-01/08)	Boite 4F27E avtomatski menjalnik s 4.prestavami
6 (GG, GY) 2.0 Di MZR-CD 100KW(136PS/HP) - 1998cc - Motor RF5C	(06/02-02/05)	Boite 4F27E avtomatski menjalnik s 4.prestavami
6 (GG, GY) 2.3 16V 120KW(163PS/HP) - 2261cc - Motor L3C1	(03/05-07/07)	Boite 4F27E avtomatski menjalnik s 4.prestavami
6 (GG, GY) 2.3 16V 122KW(166PS/HP) - 2261cc - Motor L333, L3C1, L3R4, L3R5	(05/02-01/08)	Boite 4F27E avtomatski menjalnik s 4.prestavami
6 (GG, GY) 2.3 16V MPS 191KW(260PS/HP) - 2261cc - Motor L3KG	(12/05-01/08)	Boite 4F27E avtomatski menjalnik s 4.prestavami
Premacy 1.8 84KW(115PS/HP) - 1840cc - Motor FP	(08/99-10/01)	Boite 4F27E avtomatski menjalnik s 4.prestavami
Premacy 2.0 96KW(130PS/HP) - 1991cc - Motor FS7G	(12/01-06/05)	Boite 4F27E avtomatski menjalnik s 4.prestavami