

# TEK021

## CITROEN

C5 I 1.6 HDi 16V 80KW(110PS/HP) - 1560cc - Motor DV6TED4	(09/04-02/08)	Boite4HP20 avtomatski menjalnik s 4.prestavami
C5 I 1.8 16V 85KW(115PS/HP) - 1749cc - Motor EW7J4	(03/01-10/04)	Boite4HP20 avtomatski menjalnik s 4.prestavami
C5 I 1.8 16V 92KW(125PS/HP) - 1749cc - Motor EW7A	(09/05-02/08)	Boite4HP20 avtomatski menjalnik s 4.prestavami
C5 I 1.8 16V 86KW(117PS/HP) - 1749cc - Motor EW7J4	(09/04-02/08)	Boite4HP20 avtomatski menjalnik s 4.prestavami
C5 I 2.0 HDi 66KW(90PS/HP) - 1997cc - Motor DW10TD	(05/02-10/04)	Boite4HP20 avtomatski menjalnik s 4.prestavami
C5 I 2.0 HDi 80KW(110PS/HP) - 1997cc - Motor DW10ATED	(11/00-10/04)	Boite4HP20 avtomatski menjalnik s 4.prestavami
C5 I 2.0 HDi 16V 100KW(138PS/HP) - 1997cc - Motor DW10BTED4	(09/04-02/08)	Boite4HP20 avtomatski menjalnik s 4.prestavami
C5 I 2.0 HPI 103KW(143PS/HP) - 1998cc - Motor EW10D	(11/00-10/04)	Boite4HP20 avtomatski menjalnik s 4.prestavami
C5 I 2.0i 16V 103KW(143PS/HP) - 1997cc - Motor EW10A	(09/04-02/08)	Boite4HP20 avtomatski menjalnik s 4.prestavami
C5 I 2.0i 16V 99KW(136PS/HP) - 1997cc - Motor EW10J4	(11/00-10/04)	Boite4HP20 avtomatski menjalnik s 4.prestavami
C5 I 2.2 HDi 16V 100KW(138PS/HP) - 2179cc - Motor DW12ATED4	(11/00-10/04)	Boite4HP20 avtomatski menjalnik s 4.prestavami
C5 I 2.2 HDi 16V 125KW(173PS/HP) - 2179cc - Motor DW12BTED4	(04/06-02/08)	Boite4HP20 avtomatski menjalnik s 4.prestavami
C5 I 2.2 HDi 16V 98KW(136PS/HP) - 2179cc - Motor DW12TED4	(09/04-02/08)	Boite4HP20 avtomatski menjalnik s 4.prestavami
C5 I 3.0 V6 24V 152KW(210PS/HP) - 2949cc - Motor ES9J4S	(11/00-10/04)	Boite4HP20 avtomatski menjalnik s 4.prestavami
C5 I 3.0 V6 24V 152KW(210PS/HP) - 2946cc - Motor ES9A	(09/04-02/08)	Boite4HP20 avtomatski menjalnik s 4.prestavami
C5 II 2.2 HDi 120KW(163PS/HP) - 2179cc - Motor DW12BTED4	(02/08-)	Boite4HP20 avtomatski menjalnik s 4.prestavami
C5 II 3.0i V6 155KW(215PS/HP) - 2946cc - Motor ES9A	(02/08-)	Boite4HP20 avtomatski menjalnik s 4.prestavami
C8 3.0 V6 150KW(208PS/HP) - 2946cc - Motor ES9J4S	(01/03-06/07)	Boite4HP20 avtomatski menjalnik s 4.prestavami
Xantia 3.0 V6 24V 143KW(194PS/HP) - 2946cc - Motor ES9J4	(09/96-12/99)	Boite4HP20 avtomatski menjalnik s 4.prestavami
XM 3.0 V6 24V 143KW(194PS/HP) - 2946cc - Motor ES9	(07/97-10/00)	Boite4HP20 avtomatski menjalnik s 4.prestavami
XM 3.0 V6, 3.0 V6 24V 125/147KW(170/200PS/HP) - 2946cc - Motor ZPJUFZ	(05/89-10/00)	Boite4HP20 avtomatski menjalnik s 4.prestavami

## PEUGEOT

406 1.6 66KW(90PS/HP) - 1580cc - Motor XU5JP	(07/96-05/04)	Boite4HP20 avtomatski menjalnik s 4.prestavami
406 1.8 74KW(101PS/HP) - 1761cc - Motor XU7JP	(10/96-03/99)	Boite4HP20 avtomatski menjalnik s 4.prestavami
406 1.8 66KW(90PS/HP) - 1761cc - Motor XU7JB	(05/97-12/00)	Boite4HP20 avtomatski menjalnik s 4.prestavami
406 1.8 16V	(07/96-10/04)	Boite4HP20 avtomatski menjalnik s 4.prestavami

82/85KW(112/116PS/HP) - 1761cc - Motor XU7JP4, EW7J4		Boite4HP20 avtomatski menjalnik s 4.prestavami
406 2.0 16V	(10/95-10/04)	
99/101KW(135/138PS/HP) - 1998cc - Motor XU10J4R, EW10J4		Boite4HP20 avtomatski menjalnik s 4.prestavami
406 2.0 HDi	(03/99-10/04)	
81KW(110PS/HP) - 1997cc - Motor DW10ATED		Boite4HP20 avtomatski menjalnik s 4.prestavami
406 2.0 HDi	(03/99-10/04)	
66KW(90PS/HP) - 1997cc - Motor DW10ATD		Boite4HP20 avtomatski menjalnik s 4.prestavami
406 2.0 HPi	(08/01-10/04)	
103KW(143PS/HP) - 1997cc - Motor EW10D		Boite4HP20 avtomatski menjalnik s 4.prestavami
406 2.2 16V	(09/00-10/04)	
118KW(160PS/HP) - 2230cc - Motor EW12J4		Boite4HP20 avtomatski menjalnik s 4.prestavami
406 2.2 HDi 16V	(11/00-12/04)	
100KW(136PS/HP) - 2179cc - Motor DW12TED4		Boite4HP20 avtomatski menjalnik s 4.prestavami
406 3.0 V6	(10/96-10/04)	
143KW(194PS/HP) - 2946cc - Motor ES9J4		Boite4HP20 avtomatski menjalnik s 4.prestavami
406 Coupé 2.0 16V	(03/97-12/04)	
100KW(135PS/HP) - 1998cc - Motor XU10J4R, EW10J4		Boite4HP20 avtomatski menjalnik s 4.prestavami
406 Coupé 2.2 16V	(03/02-12/04)	
118KW(160PS/HP) - 2230cc - Motor EW12J4		Boite4HP20 avtomatski menjalnik s 4.prestavami
406 Coupé 3.0 V6	(03/97-12/04)	
143/152KW(194/207PS/HP) - 2946cc - Motor ES9J4, ES9J4S		Boite4HP20 avtomatski menjalnik s 4.prestavami
407 1.6 HDi 16V	(04/04-12/10)	
81KW(110PS/HP) - 1560cc - Motor DV6TED4		Boite4HP20 avtomatski menjalnik s 4.prestavami
407 1.8 16V	(10/05-12/10)	
92KW(125PS/HP) - 1749cc - Motor EW7A		Boite4HP20 avtomatski menjalnik s 4.prestavami
407 1.8 16V	(03/04-07/05)	
85KW(116PS/HP) - 1749cc - Motor EW7J4		Boite4HP20 avtomatski menjalnik s 4.prestavami
407 2.0 16V	(05/05-12/10)	
103KW(140PS/HP) - 1997cc - Motor EW10A		Boite4HP20 avtomatski menjalnik s 4.prestavami
407 2.0 16V	(03/04-07/05)	
100KW(136PS/HP) - 1997cc - Motor EW10J4		Boite4HP20 avtomatski menjalnik s 4.prestavami
407 2.0 HDi 16V	(10/08-12/10)	
103KW(140PS/HP) - 1997cc - Motor DW10BTED4		Boite4HP20 avtomatski menjalnik s 4.prestavami
407 2.0 HDi 16V	(03/04-12/10)	
100KW(136PS/HP) - 1997cc - Motor DW10BTED4		Boite4HP20 avtomatski menjalnik s 4.prestavami
407 2.0 HDi 16V	(06/09-12/10)	
120KW(163PS/HP) - 1997cc - Motor DW10CTED4		Boite4HP20 avtomatski menjalnik s 4.prestavami
407 2.2 16V	(08/05-12/10)	
120KW(163PS/HP) - 2230cc - Motor EW12J4		Boite4HP20 avtomatski menjalnik s 4.prestavami
407 2.2 16V	(03/04-07/05)	
117KW(160PS/HP) - 2230cc - Motor EW12J4		Boite4HP20 avtomatski menjalnik s 4.prestavami
407 2.2 HDi 16V	(03/06-12/10)	
125KW(170PS/HP) - 2179cc - Motor DW12BTED4		Boite4HP20 avtomatski menjalnik s 4.prestavami
407 2.7 HDi V6	(10/05-12/10)	
150KW(204PS/HP) - 2720cc - Motor DT17TED4		Boite4HP20 avtomatski menjalnik s 4.prestavami
407 3.0 HDi V6	(07/09-12/10)	
177KW(240PS/HP) - 2992cc - Motor DT20C		Boite4HP20 avtomatski menjalnik s 4.prestavami
407 3.0 V6	(03/04-12/10)	
155KW(211PS/HP) - 2946cc - Motor ES9A		Boite4HP20 avtomatski menjalnik s 4.prestavami
407 SW 1.8 16V	(10/05-12/10)	
92KW(125PS/HP) - 1749cc - Motor EW7A		Boite4HP20 avtomatski menjalnik s 4.prestavami
407 SW 2.0 16V	(05/05-12/10)	
103KW(140PS/HP) - 1997cc - Motor EW10A		Boite4HP20 avtomatski menjalnik s 4.prestavami
407 SW 2.2 HDi 16V	(03/06-12/10)	
125KW(170PS/HP) - 2179cc - Motor DW12BTED4		Boite4HP20 avtomatski menjalnik s 4.prestavami
607 2.0 16V	(02/00-07/04)	
100KW(136PS/HP) - 1997cc - Motor EW10J4		Boite4HP20 avtomatski menjalnik s 4.prestavami
607 2.0 HDi	(09/05-07/11)	
100KW(136PS/HP) - 1997cc - Motor DW10BTE		Boite4HP20 avtomatski menjalnik s 4.prestavami
607 2.0 HDi	(03/01-07/04)	
81KW(110PS/HP) - 1997cc - Motor DW10ATED		Boite4HP20 avtomatski menjalnik s 4.prestavami

03/11/2023

607 2.2 16V 118KW(160PS/HP) - 2230cc - Motor EW12J4	(03/00-08/05)	Boite4HP20 avtomatski menjalnik s 4.prestavami
607 2.2 16V 120KW(163PS/HP) - 2230cc - Motor EW12J4	(09/05-06/10)	Boite4HP20 avtomatski menjalnik s 4.prestavami
607 2.2 HDi 16V 125KW(170PS/HP) - 2179cc - Motor DW12BTED4	(05/06-06/10)	Boite4HP20 avtomatski menjalnik s 4.prestavami
607 2.2 HDi 16V 98KW(136PS/HP) - 2179cc - Motor DW12TED4	(03/00-02/06)	Boite4HP20 avtomatski menjalnik s 4.prestavami
607 2.7 HDi V6 150KW(204PS/HP) - 2721cc - Motor DT17TED4	(11/04-07/11)	Boite4HP20 avtomatski menjalnik s 4.prestavami
607 3.0 V6 24V 155KW(211PS/HP) - 2946cc - Motor ES9A	(08/04-07/11)	Boite4HP20 avtomatski menjalnik s 4.prestavami
607 3.0 V6 24V 154KW(210PS/HP) - 2946cc - Motor ES9J4S	(03/00-07/04)	Boite4HP20 avtomatski menjalnik s 4.prestavami
807 3.0 V6 150KW(208PS/HP) - 2946cc - Motor ES9J4S	(09/02-05/06)	Boite4HP20 avtomatski menjalnik s 4.prestavami