

TEK053

AUDI

A4 (8D, B5) 1.6 74KW(100PS/HP) - 1595cc - Motor ADP, AHL, ANA, ARM	(11/94-09/01)	Boite 01V avtomatski menjalnik s 5.prestavami
A4 (8D, B5) 1.8 20V 85KW(115PS/HP) - 1781cc - Motor AFY	(04/95-10/01)	Boite 01V avtomatski menjalnik s 5.prestavami
A4 (8D, B5) 1.8 20V 92KW(125PS/HP) - 1781cc - Motor ADR, APT, ARG	(11/94-09/01)	Boite 01V avtomatski menjalnik s 5.prestavami
A4 (8D, B5) 1.8 20V Turbo 131KW(180PS/HP) - 1781cc - Motor AJL	(12/97-09/01)	Boite 01V avtomatski menjalnik s 5.prestavami
A4 (8D, B5) 1.8 20V Turbo 110KW(150PS/HP) - 1781cc - Motor AEB, ANB, APU, ARK, AWT	(11/94-09/01)	Boite 01V avtomatski menjalnik s 5.prestavami
A4 (8D, B5) 1.9 TD 55KW(75PS/HP) - 1896cc - Motor AFF	(03/96-10/01)	Boite 01V avtomatski menjalnik s 5.prestavami
A4 (8D, B5) 1.9 TDi 66KW(90PS/HP) - 1896cc - Motor 1Z, AHU, AHH	(11/94-09/01)	Boite 01V avtomatski menjalnik s 5.prestavami
A4 (8D, B5) 1.9 TDi 81KW(110PS/HP) - 1896cc - Motor AFN, AVG	(11/94-09/01)	Boite 01V avtomatski menjalnik s 5.prestavami
A4 (8D, B5) 1.9 TDi 85KW(115PS/HP) - 1896cc - Motor AJM, ATJ	(04/99-09/01)	Boite 01V avtomatski menjalnik s 5.prestavami
A4 (8D, B5) 2.4 V6 123KW(165PS/HP) - 2393cc - Motor AGA, ALF, AJG, AML, APS, APZ, ARJ	(03/97-09/01)	Boite 01V avtomatski menjalnik s 5.prestavami
A4 (8D, B5) 2.5 TDi V6 110KW(150PS/HP) - 2496cc - Motor AFB, AKN	(10/97-09/01)	Boite 01V avtomatski menjalnik s 5.prestavami
A4 (8D, B5) 2.6 110KW(150PS/HP) - 2598cc - Motor ABC, ACZ	(11/94-09/01)	Boite 01V avtomatski menjalnik s 5.prestavami
A4 (8D, B5) 2.8 128KW(174PS/HP) - 2771cc - Motor AAH, AFC	(11/94-07/97)	Boite 01V avtomatski menjalnik s 5.prestavami
A4 (8D, B5) 2.8 142KW(193PS/HP) - 2771cc - Motor ACK, ALG, APR, AQD, ATX	(10/96-09/01)	Boite 01V avtomatski menjalnik s 5.prestavami
A4 (8D, B5) RS4 2.7 V6 Biturbo 280KW(380PS/HP) - 2671cc - Motor ASJ, AZR	(05/00-09/01)	Boite 01V avtomatski menjalnik s 5.prestavami
A4 (8D, B5) S4 2.7 V6 30V 195KW(265PS/HP) - 2671cc - Motor AGB	(09/97-11/00)	
A4 (8E, 8H, B6) 1.6 75KW(102PS/HP) - 1595cc - Motor ALZ	(01/01-06/08)	Boite 01V avtomatski menjalnik s 5.prestavami
A4 (8E, 8H, B6) 1.8 20V Turbo 120KW(163PS/HP) - 1781cc - Motor BFB	(11/04-09/08)	Boite 01V avtomatski menjalnik s 5.prestavami
A4 (8E, 8H, B6) 1.8 20V Turbo 120KW(163PS/HP) - 1781cc - Motor BFB	(06/02-09/08)	Boite 01V avtomatski menjalnik s 5.prestavami
A4 (8E, 8H, B6) 1.8 20V Turbo 125KW(170PS/HP) - 1781cc - Motor AMB	(07/01-12/04)	Boite 01V avtomatski menjalnik s 5.prestavami
A4 (8E, 8H, B6) 1.8 20V Turbo 110KW(150PS/HP) - 1781cc - Motor AVJ, AUM	(11/00-08/02)	Boite 01V avtomatski menjalnik s 5.prestavami
A4 (8E, 8H, B6) 1.8 20V Turbo 140KW(190PS/HP) - 1781cc - Motor BEX	(11/02-12/04)	Boite 01V avtomatski menjalnik s 5.prestavami
A4 (8E, 8H, B6) 1.9 TDi 85KW(115PS/HP) - 1896cc - Motor BKE, BRB	(05/04-06/08)	Boite 01V avtomatski menjalnik s 5.prestavami
A4 (8E, 8H, B6) 1.9 TDi 73KW(100PS/HP) - 1896cc - Motor AVB	(03/01-08/04)	Boite 01V avtomatski menjalnik s 5.prestavami
A4 (8E, 8H, B6) 1.9 TDi 96KW(130PS/HP) - 1896cc - Motor AVF, AWX	(11/00-06/08)	Boite 01V avtomatski menjalnik s 5.prestavami
A4 (8E, 8H, B6) 2.0 20V 96KW(130PS/HP) - 1984cc - Motor ALT	(11/00-06/08)	Boite 01V avtomatski menjalnik s 5.prestavami

A4 (8E, 8H, B6) 2.0 FSi 110KW(150PS/HP) - 1984cc - Motor AWA	(07/02-01/05)	Boite 01V avtomatski menjalnik s 5.prestavami
A4 (8E, 8H, B6) 2.0 TDi 125KW(170PS/HP) - 1968cc - Motor BRD, BVA	(05/06-06/08)	Boite 01V avtomatski menjalnik s 5.prestavami
A4 (8E, 8H, B6) 2.0 TDi 103KW(140PS/HP) - 1968cc - Motor BLB, BNA, BRE, BRF	(11/04-06/08)	Boite 01V avtomatski menjalnik s 5.prestavami
A4 (8E, 8H, B6) 2.0 TFSi 147KW(200PS/HP) - 1984cc - Motor BGB, BWE	(11/04-09/08)	Boite 01V avtomatski menjalnik s 5.prestavami
A4 (8E, 8H, B6) 2.0 TFSi 162KW(220PS/HP) - 1984cc - Motor BUL	(06/05-06/08)	Boite 01V avtomatski menjalnik s 5.prestavami
A4 (8E, 8H, B6) 2.4 V6 125KW(170PS/HP) - 2393cc - Motor BDV	(09/01-06/08)	Boite 01V avtomatski menjalnik s 5.prestavami
A4 (8E, 8H, B6) 2.4 V6 120KW(163PS/HP) - 2393cc - Motor AMM	(09/01-06/08)	Boite 01V avtomatski menjalnik s 5.prestavami
A4 (8E, 8H, B6) 2.5 TDi V6 131KW(180PS/HP) - 2496cc - Motor AKE, BAU, BDH	(11/00-12/05)	Boite 01V avtomatski menjalnik s 5.prestavami
A4 (8E, 8H, B6) 2.5 TDi V6 120KW(163PS/HP) - 2496cc - Motor BCZ	(11/04-12/05)	Boite 01V avtomatski menjalnik s 5.prestavami
A4 (8E, 8H, B6) 2.5 TDi V6 115KW(155PS/HP) - 2496cc - Motor AYM	(04/01-08/02)	Boite 01V avtomatski menjalnik s 5.prestavami
A4 (8E, 8H, B6) 2.7 TDi V6 132KW(180PS/HP) - 2698cc - Motor BPP	(11/05-09/08)	Boite 01V avtomatski menjalnik s 5.prestavami
A4 (8E, 8H, B6) 3.0 TDi V6 171KW(233PS/HP) - 2967cc - Motor ASB	(11/05-09/08)	Boite 01V avtomatski menjalnik s 5.prestavami
A4 (8E, 8H, B6) 3.0 TDi V6 150KW(204PS/HP) - 2967cc - Motor BKN	(11/04-06/08)	Boite 01V avtomatski menjalnik s 5.prestavami
A4 (8E, 8H, B6) 3.0 V6 30V 162KW(220PS/HP) - 2976cc - Motor ASN, AVK, BBJ	(11/00-06/08)	Boite 01V avtomatski menjalnik s 5.prestavami
A4 (8E, 8H, B6) 3.2 FSi 188KW(256PS/HP) - 3123cc - Motor AUK	(11/04-06/08)	Boite 01V avtomatski menjalnik s 5.prestavami
A4 (8E, 8H, B6) RS4 4.2 V8 309KW(420PS/HP) - 4163cc - Motor BNS	(09/05-12/08)	Boite 01V avtomatski menjalnik s 5.prestavami
A4 (8E, 8H, B6) S4 4.2 V8 24V 253KW(344PS/HP) - 4163cc - Motor BBK, BHF	(02/03-12/08)	
A6 (4A, 4B, C4, C5) 1.8 85KW(116PS/HP) - 1781cc - Motor AFY	(05/97-07/05)	Boite 01V avtomatski menjalnik s 5.prestavami
A6 (4A, 4B, C4, C5) 1.8 92KW(125PS/HP) - 1781cc - Motor AJP, AQE, ARH	(07/97-06/01)	Boite 01V avtomatski menjalnik s 5.prestavami
A6 (4A, 4B, C4, C5) 1.8 20V 92KW(125PS/HP) - 1781cc - Motor ADR	(12/95-02/97)	Boite 01V avtomatski menjalnik s 5.prestavami
A6 (4A, 4B, C4, C5) 1.8 20V Turbo 110KW(150PS/HP) - 1781cc - Motor AEB, ANB, APU, ARK, AWL, AWT	(01/97-07/05)	Boite 01V avtomatski menjalnik s 5.prestavami
A6 (4A, 4B, C4, C5) 1.8 20V Turbo 132KW(180PS/HP) - 1781cc - Motor AJL	(12/97-07/05)	Boite 01V avtomatski menjalnik s 5.prestavami
A6 (4A, 4B, C4, C5) 1.9 TDi 85KW(115PS/HP) - 1896cc - Motor AJM	(11/00-06/01)	Boite 01V avtomatski menjalnik s 5.prestavami
A6 (4A, 4B, C4, C5) 1.9 TDi 81KW(110PS/HP) - 1896cc - Motor AFN, AVG	(02/97-12/00)	Boite 01V avtomatski menjalnik s 5.prestavami
A6 (4A, 4B, C4, C5) 1.9 TDi 96KW(130PS/HP) - 1896cc - Motor AWX	(05/01-07/05)	Boite 01V avtomatski menjalnik s 5.prestavami
A6 (4A, 4B, C4, C5) 1.9 TDi 66KW(90PS/HP) - 1896cc - Motor 1Z	(06/94-02/97)	Boite 01V avtomatski menjalnik s 5.prestavami
A6 (4A, 4B, C4, C5) 2.0 85KW(116PS/HP) - 1984cc - Motor ABK	(06/94-02/97)	Boite 01V avtomatski menjalnik s 5.prestavami
A6 (4A, 4B, C4, C5) 2.0 74KW(101PS/HP) - 1984cc - Motor AAE	(06/94-02/97)	Boite 01V avtomatski menjalnik s 5.prestavami
A6 (4A, 4B, C4, C5) 2.0 20V 96KW(130PS/HP) - 1984cc - Motor ALT	(05/01-07/05)	Boite 01V avtomatski menjalnik s 5.prestavami
A6 (4A, 4B, C4, C5) 2.3 98KW(133PS/HP) - 2309cc - Motor AAR	(06/94-12/95)	Boite 01V avtomatski menjalnik s 5.prestavami
A6 (4A, 4B, C4, C5) 2.4	(07/95-10/97)	

110KW(150PS/HP) - 2393cc - Motor AFM		Boite 01V avtomatski menjalnik s 5.prestavami
A6 (4A, 4B, C4, C5) 2.4	(06/01-07/05)	
125KW(170PS/HP) - 2393cc - Motor BDV		Boite 01V avtomatski menjalnik s 5.prestavami
A6 (4A, 4B, C4, C5) 2.4	(02/97-06/01)	
121KW(165PS/HP) - 2393cc - Motor AGA, AJG, ALF, ALW, APS, APZ, ARJ, ARN		Boite 01V avtomatski menjalnik s 5.prestavami
A6 (4A, 4B, C4, C5) 2.4	(07/98-06/01)	
100KW(136PS/HP) - 2393cc - Motor ALW		Boite 01V avtomatski menjalnik s 5.prestavami
A6 (4A, 4B, C4, C5) 2.4	(02/97-07/05)	
115KW(156PS/HP) - 2393cc - Motor APC		Boite 01V avtomatski menjalnik s 5.prestavami
A6 (4A, 4B, C4, C5) 2.5 Tdi	(07/97-06/01)	
110KW(150PS/HP) - 2496cc - Motor AFB, AKN		Boite 01V avtomatski menjalnik s 5.prestavami
A6 (4A, 4B, C4, C5) 2.5 TDi	(06/94-02/97)	
85KW(116PS/HP) - 2496cc - Motor AAT		Boite 01V avtomatski menjalnik s 5.prestavami
A6 (4A, 4B, C4, C5) 2.5 Tdi	(07/99-07/05)	
132KW(180PS/HP) - 2496cc - Motor AKE, BAU, BDH		Boite 01V avtomatski menjalnik s 5.prestavami
A6 (4A, 4B, C4, C5) 2.5 Tdi	(07/02-07/05)	
120KW(163PS/HP) - 2496cc - Motor BCZ, BDG, BFC		Boite 01V avtomatski menjalnik s 5.prestavami
A6 (4A, 4B, C4, C5) 2.5 Tdi	(04/01-07/05)	
115KW(155PS/HP) - 2496cc - Motor AYM		Boite 01V avtomatski menjalnik s 5.prestavami
A6 (4A, 4B, C4, C5) 2.6 V6	(06/94-02/97)	
102KW(139PS/HP) - 2598cc - Motor ACZ		Boite 01V avtomatski menjalnik s 5.prestavami
A6 (4A, 4B, C4, C5) 2.6 V6	(06/94-02/97)	
110KW(150PS/HP) - 2598cc - Motor ABC		Boite 01V avtomatski menjalnik s 5.prestavami
A6 (4A, 4B, C4, C5) 2.7 T V6	(12/97-06/01)	
169KW(230PS/HP) - 2671cc - Motor AJK		Boite 01V avtomatski menjalnik s 5.prestavami
A6 (4A, 4B, C4, C5) 2.7 T V6	(01/99-06/01)	
169KW(230PS/HP) - 2671cc - Motor AJK, AZA		Boite 01V avtomatski menjalnik s 5.prestavami
A6 (4A, 4B, C4, C5) 2.7 T V6	(05/00-07/05)	
184KW(250PS/HP) - 2671cc - Motor ARE		Boite 01V avtomatski menjalnik s 5.prestavami
A6 (4A, 4B, C4, C5) 2.8 V6	(06/94-02/97)	
128KW(174PS/HP) - 2771cc - Motor AAH		Boite 01V avtomatski menjalnik s 5.prestavami
A6 (4A, 4B, C4, C5) 2.8 V6	(07/99-06/01)	
140KW(190PS/HP) - 2771cc - Motor ATX		Boite 01V avtomatski menjalnik s 5.prestavami
A6 (4A, 4B, C4, C5) 2.8 V6	(02/97-06/01)	
142KW(193PS/HP) - 2771cc - Motor ACK, ALG, APR, AQD		Boite 01V avtomatski menjalnik s 5.prestavami
A6 (4A, 4B, C4, C5) 2.8 V6	(06/94-07/95)	
120KW(163PS/HP) - 2771cc - Motor AEJ		Boite 01V avtomatski menjalnik s 5.prestavami
A6 (4A, 4B, C4, C5) 2.8 V6	(10/97-07/98)	
132KW(180PS/HP) - 2771cc - Motor AGE		Boite 01V avtomatski menjalnik s 5.prestavami
A6 (4A, 4B, C4, C5) 2.8 V6	(12/95-02/97)	
142KW(193PS/HP) - 2771cc - Motor ACK, ALG, APR, AQD		Boite 01V avtomatski menjalnik s 5.prestavami
A6 (4A, 4B, C4, C5) 3.0 V6	(05/01-07/05)	
162KW(220PS/HP) - 2976cc - Motor ASN		Boite 01V avtomatski menjalnik s 5.prestavami
A6 (4A, 4B, C4, C5) 3.7 V8	(06/99-07/05)	
191KW(260PS/HP) - 3697cc - Motor AQG		Boite 01V avtomatski menjalnik s 5.prestavami
A6 (4A, 4B, C4, C5) 4.2	(11/98-07/05)	
220KW(300PS/HP) - 4172cc - Motor ARS, ART, ASG, AWN		Boite 01V avtomatski menjalnik s 5.prestavami
A6 (4A, 4B, C4, C5) RS6 4.2 V8 Biturbo	(07/02-10/04)	
330KW(450PS/HP) - 4172cc - Motor BCY		
A6 (4A, 4B, C4, C5) RS6 Plus 4.2 V8 Biturbo	(04/04-10/04)	
353KW(480PS/HP) - 4172cc - Motor BRV		
A6 (4A, 4B, C4, C5) S6 4.2 V8	(07/99-07/05)	
250KW(340PS/HP) - 4172cc - Motor AQJ, ANK		
A8 (4D) 2.5 TDi V6	(04/00-10/02)	
131KW(180PS/HP) - 2496cc - Motor AKE		Boite 01V avtomatski menjalnik s 5.prestavami
A8 (4D) 2.5 TDi V6	(07/97-10/02)	
110KW(150PS/HP) - 2496cc - Motor AFB, AKN		Boite 01V avtomatski menjalnik s 5.prestavami
A8 (4D) 2.8 V6 30V	(04/96-10/02)	
142KW(193PS/HP) - 2771cc - Motor ACK, ALG, AMX, APR, AQD		Boite 01V avtomatski menjalnik s 5.prestavami
A8 (4D) 2.8E	(03/94-03/96)	
128KW(174PS/HP) - 2771cc - Motor AAH		Boite 01V avtomatski menjalnik s 5.prestavami

A8 (4D) 3.3 TDi V8 167KW(225PS/HP) - 3328cc - Motor AKF	(09/99-10/02)	Boite 01V avtomatski menjalnik s 5.prestavami
A8 (4D) 3.7 169KW(230PS/HP) - 3697cc - Motor AEW, AKJ	(07/95-10/02)	Boite 01V avtomatski menjalnik s 5.prestavami
A8 (4D) 3.7 V8 40V 191KW(260PS/HP) - 3697cc - Motor AQG, AKC	(10/98-10/02)	Boite 01V avtomatski menjalnik s 5.prestavami
A8 (4D) 4.2 V8 220KW(300PS/HP) - 4172cc - Motor ABZ	(03/94-07/96)	Boite 01V avtomatski menjalnik s 5.prestavami
A8 (4D) 4.2 V8 175KW(239PS/HP) - 4172cc - Motor ARU, AVN	(05/99-10/02)	Boite 01V avtomatski menjalnik s 5.prestavami
A8 (4D) 4.2 V8 264KW(360PS/HP) - 4172cc - Motor AQH, AVP	(05/99-10/02)	Boite 01V avtomatski menjalnik s 5.prestavami
A8 (4D) 4.2 V8 40V 228KW(310PS/HP) - 4172cc - Motor AQF, AUX, AUW	(10/98-10/02)	Boite 01V avtomatski menjalnik s 5.prestavami
A8 (4D) 6.0 W12 309KW(420PS/HP) - 5998cc - Motor AZC	(06/01-10/02)	Boite 01V avtomatski menjalnik s 5.prestavami
A8 (4D) S8 4.2 250KW(340PS/HP) - 4172cc - Motor AHC	(07/96-10/02)	
Allroad (4BH) 2.5 TDi V6 132KW(180PS/HP) - 2496cc - Motor AKE, BAU	(05/00-08/05)	
Allroad (4BH) 2.7 Turbo V6 184KW(250PS/HP) - 2671cc - Motor ARE, BES	(05/00-08/05)	
Allroad (4BH) 4.2 V8 220KW(300PS/HP) - 4163cc - Motor BAS	(06/02-08/05)	

PORSCHE

Boxster (987) 2.7 176KW(240PS/HP) - 2687cc - Motor M 96.25	(11/04-12/08)	
Boxster (987) 2.7 180KW(245PS/HP) - 2687cc - Motor M97.20	(08/06-01/09)	
Boxster (987) S 3,4 223KW(303PS/HP) - 3387cc - Motor M9722	(01/08-12/10)	
Boxster (987) S 3.2 206KW(280PS/HP) - 3179cc - Motor M 96.26	(11/04-01/09)	
Boxster (987) S 3.4 217KW(295PS/HP) - 3387cc - Motor M97.21	(08/06-12/10)	
Boxster 2.5i (986) 150KW(204PS/HP) - 2480cc - Motor M96.20	(09/96-05/00)	
Boxster 2.7 (986) 155KW(208PS/HP) - 2687cc - Motor M9622	(06/99-12/01)	
Boxster 2.7 (986) 168KW(228PS/HP) - 2687cc - Motor M9623	(08/02-07/04)	
Boxster 2.7i (986) 162KW(220PS/HP) - 2687cc - Motor M96.22, M96.23	(08/99-02/05)	
Boxster S 3.2 24V 196KW(266PS/HP) - 3179cc - Motor M96.245	(01/04-12/04)	
Boxster S 3.2 24V 185/191KW(252/260PS/HP) - 3179cc - Motor M96.21, M96.24	(08/99-02/05)	
Cayman (987) 2.7 180KW(245PS/HP) - 2687cc - Motor M 97.20	(07/06-01/09)	
Cayman (987) S 3.4 217KW(295PS/HP) - 3387cc - Motor M 97.21	(11/05-01/09)	
Cayman (987) S 3.4 223KW(299PS/HP) - 3387cc - Motor M9722	(08/08-01/09)	

SKODA

Superb I 1.8 20V Turbo 110KW(150PS/HP) - 1781cc - Motor AWT	(06/02-03/08)	
Superb I 1.9 TDi 96KW(130PS/HP) - 1896cc - Motor AWX	(06/02-03/08)	

Superb I 1.9 TDi 77KW(105PS/HP) - 1896cc - Motor BSV	(09/05-05/07)
Superb I 1.9 TDi 85KW(115PS/HP) - 1896cc - Motor BPZ	(02/07-03/08)
Superb I 1.9 TDi 74KW(100PS/HP) - 1896cc - Motor AVB	(06/02-10/05)
Superb I 2.0 85KW(115PS/HP) - 1984cc - Motor AZM	(06/02-03/08)
Superb I 2.0 TDi 103KW(140PS/HP) - 1968cc - Motor BSS	(09/05-03/08)
Superb I 2.5 TDi V6 114KW(155PS/HP) - 2496cc - Motor AYM	(06/02-08/03)
Superb I 2.5 TDi V6 120KW(163PS/HP) - 2496cc - Motor BDG	(06/03-03/08)
Superb I 2.8 V6 142KW(193PS/HP) - 2771cc - Motor AMX, BBG	(06/02-03/08)

VOLKSWAGEN

Passat (3B2/3B5) 1.6 74KW(101PS/HP) - 1595cc - Motor ADP, AHL, ANA, ARM	(10/96-12/00)	Boite 01V avtomatski menjalnik s 5.prestavami
Passat (3B2/3B5) 1.8 85KW(116PS/HP) - 1781cc - Motor AFY	(01/97-11/00)	Boite 01V avtomatski menjalnik s 5.prestavami
Passat (3B2/3B5) 1.8 20V 92KW(125PS/HP) - 1781cc - Motor ADR, APW, ARG	(10/96-12/00)	Boite 01V avtomatski menjalnik s 5.prestavami
Passat (3B2/3B5) 1.8 20V Turbo 110KW(150PS/HP) - 1781cc - Motor AEB, ANB, APU	(10/96-12/00)	Boite 01V avtomatski menjalnik s 5.prestavami
Passat (3B2/3B5) 1.9 TDi 85KW(115PS/HP) - 1896cc - Motor AJM, ATJ	(08/98-12/00)	Boite 01V avtomatski menjalnik s 5.prestavami
Passat (3B2/3B5) 1.9 TDi 66KW(90PS/HP) - 1896cc - Motor AHH, AHU	(10/96-12/00)	Boite 01V avtomatski menjalnik s 5.prestavami
Passat (3B2/3B5) 1.9 TDi 81KW(110PS/HP) - 1896cc - Motor AFN, AVG	(10/96-12/00)	Boite 01V avtomatski menjalnik s 5.prestavami
Passat (3B2/3B5) 2.3 V5 110KW(150PS/HP) - 2324cc - Motor AGZ	(10/96-10/00)	Boite 01V avtomatski menjalnik s 5.prestavami
Passat (3B2/3B5) 2.5 TDi V6 110KW(150PS/HP) - 2496cc - Motor AFB	(11/98-12/00)	Boite 01V avtomatski menjalnik s 5.prestavami
Passat (3B2/3B5) 2.8 V6 142KW(193PS/HP) - 2771cc - Motor ACK, ALG	(10/96-12/00)	Boite 01V avtomatski menjalnik s 5.prestavami
Passat (3B2/3B5) 2.8 V6 132KW(180PS/HP) - 2771cc - Motor AGE	(05/97-09/99)	Boite 01V avtomatski menjalnik s 5.prestavami
Passat (3B3/3B6) 1.6 75KW(102PS/HP) - 1595cc - Motor ALZ	(11/00-09/05)	Boite 01V avtomatski menjalnik s 5.prestavami
Passat (3B3/3B6) 1.8 20V Turbo 110KW(150PS/HP) - 1781cc - Motor AWT	(11/00-09/05)	Boite 01V avtomatski menjalnik s 5.prestavami
Passat (3B3/3B6) 1.9 TDi 74KW(101PS/HP) - 1896cc - Motor AVB	(11/00-09/05)	Boite 01V avtomatski menjalnik s 5.prestavami
Passat (3B3/3B6) 1.9 TDi 96KW(130PS/HP) - 1896cc - Motor AVF, AWX	(11/00-09/05)	Boite 01V avtomatski menjalnik s 5.prestavami
Passat (3B3/3B6) 2.0 85KW(115PS/HP) - 1984cc - Motor AZM	(11/00-09/05)	Boite 01V avtomatski menjalnik s 5.prestavami
Passat (3B3/3B6) 2.0 96KW(130PS/HP) - 1984cc - Motor ALT	(11/01-09/05)	Boite 01V avtomatski menjalnik s 5.prestavami
Passat (3B3/3B6) 2.0 TDi 100KW(136PS/HP) - 1968cc - Motor BGW, BHW	(12/03-09/05)	Boite 01V avtomatski menjalnik s 5.prestavami
Passat (3B3/3B6) 2.3 V5 20V 125KW(170PS/HP) - 2324cc - Motor AZX	(11/00-09/05)	Boite 01V avtomatski menjalnik s 5.prestavami
Passat (3B3/3B6) 2.5 TDi V6 132KW(180PS/HP) - 2496cc - Motor BDH	(01/03-09/05)	Boite 01V avtomatski menjalnik s 5.prestavami
Passat (3B3/3B6) 2.5 TDi V6 110KW(150PS/HP) - 2496cc - Motor AKN	(11/00-09/05)	Boite 01V avtomatski menjalnik s 5.prestavami

Passat (3B3/3B6) 2.5 TDi V6 120KW(163PS/HP) - 2496cc - Motor BAU	(05/03-09/05)	Boite 01V avtomatski menjalnik s 5.prestavami
Passat (3B3/3B6) 2.8 VR6 142KW(193PS/HP) - 2771cc - Motor AMX, ATQ, BBG	(11/00-09/05)	Boite 01V avtomatski menjalnik s 5.prestavami
Passat (3B3/3B6) 4.0 W8 4-Motion 202KW(275PS/HP) - 3999cc - Motor BDN	(11/01-12/04)	Boite 01V avtomatski menjalnik s 5.prestavami
Passat (3B3/3B6) 1.8 20V Turbo 125KW(170PS/HP) - 1781cc - Motor AWM	(02/01-09/05)	Boite 01V avtomatski menjalnik s 5.prestavami
Passat (3C2/3C5) 1.6 FSi 85KW(115PS/HP) - 1598cc - Motor BLF	(03/05-06/08)	Boite 01V avtomatski menjalnik s 5.prestavami
Passat (3C2/3C5) 2.0 FSi 110KW(150PS/HP) - 1984cc - Motor BLR, BLX, BLY, BVX, BVY, BVZ	(03/05-11/10)	Boite 01V avtomatski menjalnik s 5.prestavami
Passat (3C2/3C5) 2.0 TDi 103KW(140PS/HP) - 1968cc - Motor BKP, BMP, CBAB	(03/05-07/10)	Boite 01V avtomatski menjalnik s 5.prestavami
Passat (3C2/3C5) 3.2 FSi 184KW(250PS/HP) - 3168cc - Motor AXZ	(11/05-11/10)	Boite 01V avtomatski menjalnik s 5.prestavami
Phaeton 3.0 TDi V6 165KW(224PS/HP) - 2967cc - Motor BMK	(09/04-07/07)	Boite 01V avtomatski menjalnik s 5.prestavami
Phaeton 3.2 V6 177KW(241PS/HP) - 3189cc - Motor AYT, BKL, BRK	(03/02-05/07)	Boite 01V avtomatski menjalnik s 5.prestavami
Phaeton 4.2 V8 246KW(335PS/HP) - 4172cc - Motor BGH, BGJ	(07/03-)	Boite 01V avtomatski menjalnik s 5.prestavami
Phaeton 5.0 TDi V10 230KW(313PS/HP) - 4921cc - Motor AJS	(03/03-05/06)	Boite 01V avtomatski menjalnik s 5.prestavami
Phaeton 6.0 W12 331KW(450PS/HP) - 5998cc - Motor BRN, BTT	(06/05-)	Boite 01V avtomatski menjalnik s 5.prestavami
Phaeton 6.0 W12 309KW(420PS/HP) - 5998cc - Motor BAN	(03/02-05/05)	Boite 01V avtomatski menjalnik s 5.prestavami
Transporter T4 2.4 Diesel 57KW(78PS/HP) - 2370cc - Motor AAB	(10/90-08/03)	